

New vs. Old Reserve Cable/ RSL Routing

OLD STYLE

Reserve Boost Lanyard
over the Housing

Housing Retainer-
above the Top Closing
Flap.



Reserve Ripcord- through
both rings and under the
Housing.

NEW STYLE

Housing - under the Top
Closing Flap.

Reserve Boost Lanyard
over the Housing

Reserve Ripcord- through
both rings.

