

REPLACING THE WINGS CUTAWAY HANDLE

To replace the Cutaway Handle of the **WINGS** Harness/ Container:

1. Feed the shorter of the two yellow cables into the **RIGHT** cable housing.
2. Feed the longer yellow cable into the **LEFT** cable housing which is the RSL side.
3. Trim the shorter cable (RIGHT side) to 5" (12.7 cm.) from the opening of the cable housing as shown. (fig. 1)
4. Trim the longer (LEFT side) to 6" (15.24 cm.) from the opening of the cable housing. (fig. 2)
5. Lightly melt the ends of the yellow cable to smooth ends to prevent damage to the T-II loop.



fig. 1

Right Side



fig. 2

Left Side

Place Main Risers
On Top Of This Flap